

Tools required: straight edge, utility knife, tape measure and safety goggles



Measure the width of each panel frame and cut the panels to the proper size.



Measure the height of each panel frame and cut the panels to the proper size.



The panels are scored allowing them to flex for an easy installation.



Insert the panel (laminated side facing outward) under one horizontal rail, carefully bending it in order to place the other side behind the opposite rail.



Continue step 5 for the rest of the panels.

*Please ensure that all appropriate safety precautions are taken when fabricating and installing this product.

